



Eight numbers (1 to 8) are printed on the surface of the filter.

The following explains the procedure for tightening filters using these numbers.

- Make a mark on the cylinder block under the number that shows at the bottom of the filter when the rubber seal is seated.
- 2) Tighten the filter by turning it clockwise seven numbers from the marked point. For example, if a mark is made under the number 2 when the rubber seal is seated, the filter should be tightened until the number 1 aligns with the marked point.





Number when rubber seal is seated.


Number after tightening.

Number when rubber seal is seated	1	2	3	4	5	6	7	8
Number after tightening	8	1	2	3	4	5	6	7

After installation, fill the engine with oil up to the specified level, run the engine for more than 3 minutes, then check for oil leakage.

Spark Plug Inspection -


- 1. Remove the plug wire cover and the plug wires.
- Remove the plug wire clamps while pulling up on the lock



Engine Tune-up

- Spark Plug Inspection (cont'd)

3. Inspect the electrodes and ceramic insulator for:



Burned or worn electrodes may be caused by:

- Lean fuel mixture
- · Advanced ignition timing
- Loose spark plug
- Plug heat range too high
- Insufficient cooling

Fouled plug may be caused by:


- Rich fuel mixture
- · Retarded ignition timing
- · Oil in combustion chamber
- · Incorrect spark plug gap
- · Plug heat range too low
- Excessive idling/low speed running
- · Clogged air cleaner element
- · Deteriorated ignition coil or ignition wires

4. Replace the plug if the center electrode is rounded as shown below:

Spark Plug:

CAUTION: Use specified plugs only.

NGK	BKR6E-N11 (standard) BKR7E-N11
ND	K20PR-L11 (standard) K22PR-L11



5. Adjust the gap with a suitable gapping tool,

Electrode Gap: 1.0-1.1 mm (0.039-0.043 in)

Screw the plugs into the cylinder head finger tight, then torque them to 18 N·m (1.8 kg·m, 13 lb-ft).

NOTE: Apply a small quantity of anti-seize compound to the plug threads before installing.