

Troubleshooting

Flowchart


Problem Code 1: Hydraulic Controlled Components.


NOTE: The LED does not blink when the following failures occur.

- The contact points of the motor relay remain closed (the motor runs continuously even after the ignition key is removed).
- YEL/RED lead is shorted or the control unit is internally shorted the motor stops when the ignition switch is turned lock.

Pre-test steps:


- Check ALB Main (40 A) Fuse.
- Check all brake system hoses and pipes (low and high pressure) for signs of leaking bending or kinking.
- Check reservoir fluid level, and if necessary, fill to the MAX level.






Troubleshooting


Flowchart(cont'd)



ALB T-WRENCH
07HAA-SG00100



NOTE: The fluid enters the reservoir under pressure; wait 1 or 2 minutes for air bubbles to disappear and level to stabilize.



Problem code 2: Parking Brake Switch Related Problem

If the parking brake has been released, the following items are possible causes. If they are OK, check the control unit connectors for good connection. If not loose or disconnected, substitute a known-good control unit and recheck.

NOTE: Before Troubleshooting Problem Code 2, remove the ALB B2 fuse for three seconds to clear the control unit's memory, then test drive the car.

If the dash warning light and LED stay off, the probability is that the car was driven with the parking brake applied.

- The parking brake is applied for more than 30 seconds while driving.
- The brake fluid level in the master cylinder is too low.
- BLK/WHT lead is shorted between the **BRAKE** warning light and parking brake switch.
- BLK/WHT lead is shorted between the **BRAKE** warning light and brake fluid level switch.
- The **BRAKE** warning light is blown.
- BLK/WHT has an open between the **BRAKE** warning light and parking brake.
- BLK/WHT has an open between the parking brake switch and control unit.

(cont'd)

Troubleshooting

Flowchart (cont'd)

Problem Code 4-1 to 4-8: Speed Sensor

NOTE: Control unit will only indicate the higher number sub-code.

Ignition switch: OFF

Disconnect wire harness from speed sensor.

Check for resistance between sensor terminals.

Is there 500-1,000Ω?

NO

Faulty speed sensor.

YES

Disconnect the 18P connector from the control unit.

Check each wire for continuity between the sensor and control unit:

GRN/BLK: Front Right Positive
 GRN/BLU: Front Left Positive
 GRN/YEL: Rear Right Positive
 LT BLU: Rear Left Positive
 GRN: Front Right Negative
 BRN: Front Left Negative
 BLU/YEL: Rear Right Negative
 GRY: Rear Left Negative

Is there continuity?


NO

Repair open in sensor wire:


GRN/BLK: Front Right Positive GRN: Front Right Negative
 GRN/BLU: Front Left Positive BRN: Front Left Negative
 GRN/YEL: Rear Right Positive BLU/YEL: Rear Right Negative
 LT BLU: Rear Left Positive GRY: Rear Left Negative

Faulty control unit


<SENSOR SIDE CONNECTOR>



<SENSOR SIDE CONNECTOR>



<CONTROL UNIT 18P CONNECTOR>



Problem Code 5 to 5-4, 5-8: Speed Sensor(s)

Disconnect wire harness from speed sensor.

Check for resistance between sensor terminals.

Is there 500-1000 Ω?

NO → Faulty speed sensor.

YES

Disconnect the 18P connector from the control unit.

Check each wire for continuity between the sensor and control unit:
 GRN/BLK: Front Right Positive
 GRN/BLU: Front Left Positive
 GRN/YEL: Rear Right Positive
 LT BLU: Rear Left Positive
 BRN: Front Right Negative
 BRN: Front Left Negative
 BLU/YEL: Rear Right Negative
 GRY: Rear Left Negative

Is there continuity?

NO

Repair open in sensor wire:

GRN/BLK: Front Right Positive	GRN: Front Right Negative
GRN/BLU: Front Left Positive	BRN: Front Left Negative
GRN/YEL: Rear Right Positive	BLU/YEL: Rear Right Negative
LT BLU: Rear Left Positive	GRY: Rear Left Negative

YES

Reconnect the 18P connector to the control unit and connectors to the speed sensors.

Connect ALB checker to inspection connector.




Check ALB function in MODE 2 and 3.

Does it work properly?

NO → Faulty modulator.

YES

• Incorrect the air gap (page 13-47)
 • Faulty control unit.



Troubleshooting

Flowchart (cont'd)

Problem Code 6-1: Front Fail Safe Relay Circuit

Remove front fail safe relay

Check relay function (page 13-46)

Does it work properly?

NO
Faulty the front fail safe relay.

YES

Check for continuity between BLK lead of relay connector and body ground.

Is there continuity?

NO
Repair open in BLK wire between the fail safe relay and ground or poor ground.

YES

Turn ignition switch ON.

Check for voltage between BLK / YEL lead (+) and body ground (-).

Is battery voltage available?

NO
Repair open in BLK/YEL wire between the fail safe relay and No. 18 fuse (10 A).

YES

Turn ignition switch OFF.

Disconnect the 3P connectors from the front solenoids.

Check for continuity in BRN/BLK lead between fail safe relay and solenoids.


Is there continuity?

NO
Repair open in BRN/BLK wire between the solenoids and fail safe relay.

YES


(To page 13-21)

<FRONT FAIL SAFE RELAY CONNECTOR HARNESS SIDE>




View from terminal side

<FRONT SOLENOIDS CONNECTOR HARNESS SIDE>






View from terminal side



Troubleshooting

Flowchart(cont'd)

Problem Code 6-4: Rear Fail Safe Relay Circuit



(From page 13-22)

Disconnect the 18P and 12P connectors from the control unit.

Check for continuity in YEL/GRN lead between fail safe relay and control unit.

Is there continuity?

NO

Repair open in YEL/GRN wire between the relay and control unit.

YES

Check for continuity between control unit and rear solenoid.
RED/WHT: Rear Inlet
YEL/WHT: Rear Outlet

Is there continuity?


NO

Repair open in wire between the solenoid and control unit:
RED/WHT: Rear Inlet
YEL/WHT: Rear Outlet.


YES

Faulty control unit.


⟨REAR FAIL SAFE RELAY CONNECTOR HARNESS SIDE⟩



⟨REAR SOLENOID CONNECTOR HARNESS SIDE⟩




⟨CONTROL UNIT 18P CONNECTOR⟩



⟨CONTROL UNIT 12P CONNECTOR⟩

RED/WHT: from REAR IN SOL.



View from wire side

Troubleshooting

Flowchart (cont'd)

Problem Code 7-1 and 7-2 Front Solenoid Related Problem

Disconnect wire harness from front solenoids

Check for resistance between RED and BLK terminals of front solenoid.

Is there 1-3 Ω ?

NO

Faulty solenoid.

YES

Check for resistance between YEL and BLK terminals of front solenoid.

Is there 1-3 Ω ?

NO

Faulty solenoid.

YES

Disconnect the 12P connector from the control unit.

Check for continuity between control unit and front solenoid:
 RED/BLK: Front Right Inlet
 YEL/BLK: Front Right Outlet
 RED/BLU: Front Left Inlet
 YEL/BLU: Front Left Outlet.

Is there continuity?

NO

Repair open in wire:
 RED/BLK: Front Right Inlet
 YEL/BLK: Front Right Outlet
 RED/BLU: Front Left Inlet
 YEL/BLU: Front Left Outlet

YES

Check for continuity between control unit and body ground.
 RED/BLK: Front Right Inlet
 YEL/BLK: Front Right Outlet
 RED/BLU: Front Left Inlet
 YEL/BLU: Front Left Outlet

Is there continuity?

YES

Repair short in wire:
 RED/BLK: Front Right Inlet
 YEL/BLK: Front Right Outlet
 RED/BLU: Front Left Inlet
 YEL/BLU: Front Left Outlet



NO

• Faulty control unit.
 • Incorrect air gap (page 13-47)

<FRONT SOLENOID CONNECTOR>

LEFT:

RIGHT:





View from terminal side

<FRONT SOLENOIDS CONNECTOR HARNESS SIDE>


LEFT:

RIGHT:




View from terminal side


<CONTROL UNIT 12P CONNECTOR>




Problem Code 7-4: Rear Solenoid Related Problem



⟨REAR SOLENOID CONNECTOR⟩



⟨REAR SOLENOID CONNECTOR HARNESS SIDE⟩



⟨CONTROL UNIT 12P CONNECTOR⟩

