

Component Location



Index

STEERING WHEEL
Disassembly/Installation, page 11-10

IGNITION SWITCH
Steering Lock Replacement, page 11-37
Switch Test, see Electrical Section

STEERING COLUMN
Removal, page 11-11
Disassembly/Inspection, page 11-13
Reassembly, page 11-14
Installation, page 11-16

STEERING GEARBOX
Removal/Installation, page 11-5
Disassembly/Inspection, page 11-7
Reassembly, page 11-8

