



## Disassembly/Inspection

1. Remove the upper column holder, bending plate and bending plate spring.
2. Remove the tilt lock plate by removing the tilt adjusting bolt.
3. Remove the tilt lever, column hanger spring and bending plate base by removing the tilt lock bolt.
4. Position the ignition switch in "I."
5. Remove the snapping, then remove the steering shaft from bottom of the column.
6. Remove the retaining collar.

