

Maintenance Schedule

SERVICE AT THE INTERVAL OF LISTED KM (MILES) OR MONTHS, WHICHEVER OCCURS FIRST.						
ITEMS	x 1,000 km	20	40	60	80	100
	x 1,000 miles	12	24	36	48	60
	months	12	24	36	48	60
IDLE SPEED AND IDLE CO	I	I	I	I	I	I
VALVE CLEARANCE	I	I	I	I	I	I
ALTERNATOR DRIVE BELT		I	I	I	I	I
■ ENGINE OIL AND OIL FILTER	Replace every 10,000 km (6,000 miles) or 6 months					
■ TRANSMISSION OIL		R			R	
■ RADIATOR COOLANT					R*	
COOLING SYSTEM, HOSES AND CONNECTIONS		I			I	
AIR CLEANER ELEMENT (Viscous type)* ²		R			R	
AIR CLEANER ELEMENT (Dry type)* ³	R	R	R	R	R	R
FUEL FILTER		R			R	
TANK, FUEL LINE AND CONNECTIONS		I			I	
EVAPORATIVE EMISSION CONTROL SYSTEM* ⁵						I
IGNITION TIMING AND CONTROL SYSTEM		I			I	
SPARK PLUGS (For cars using unleaded gasoline)		R			R	
SPARK PLUGS (For cars using leaded gasoline)	R	R	R	R	R	R
DISTRIBUTOR CAP AND ROTOR		I			I	
IGNITION WIRING		I			I	
CRANKCASE EMISSION CONTROL SYSTEM		I			I	
BRAKE FLUID		R			R	
BRAKE HOSES AND LINES	I	I	I	I	I	I
FRONT BRAKE PADS	Inspect every 10,000 km (6,000 miles) or 6 months					
FRONT BRAKE DISCS AND CALIPERS	I	I	I	I	I	I
REAR BRAKE DISCS, CALIPERS AND PADS		I			I	
PARKING BRAKES	I	I			I	
CLUTCH RELEASE ARM TRAVEL	I	I	I	I	I	I
EXHAUST PIPE AND MUFFLER	I	I	I	I	I	I
SUSPENSION MOUNTING BOLTS	I	I	I	I	I	I
FRONT WHEEL ALIGNMENT	I	I	I	I	I	I
STEERING OPERATION, TIE ROD ENDS, STEERING GEAR BOX AND BOOTS	I	I			I	
POWER STEERING SYSTEM* ⁴	I	I	I	I	I	I
POWER STEERING PUMP BELT* ⁴		I			I	
CATALYTIC CONVERTER HEAT SHIELD (Car equipped with catalytic converter)						I

R—Replace I—Inspect. After inspection, clean, adjust, repair or replace if necessary.

■REMARK: These service intervals assume routine checking and replenishment has been done, as needed, by the customer.

*1 Thereafter, replace every 2 years or 40,000 km (24,000 miles), whichever comes first.

*2 For European and KQ types.

*3 Except for European and KQ types.

*4 Only for KQ type.

*5 For cars using unleaded gasoline and KY type.

CAUTION: The following items must be serviced more frequently on cars normally used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

"Severe driving conditions" include:

A : Repeated short distance driving

B : Driving in dusty conditions

C : Driving in severe, cold weather

D : Driving in areas using road salt or other corrosive materials

E : Driving on rough and/or muddy roads

F : Towing a trailer

R—Replace

I—Inspect. After inspection, clean, adjust, repair or replace if necessary.

Condition	Maintenance item	Maintenance operation	Interval
A B . . . F	Engine oil and oil filter	R	Every 5,000 km (3,000 miles) or 3 months
. F	Transmission oil	R	Every 20,000 km (12,000 miles) or 12 months
A B . D E F	Front brake discs and calipers	I	Every 10,000 km (6,000 miles) or 6 months
A B . D E F	Rear brakes (discs, calipers and pads)	I	Every 20,000 km (12,000 miles) or 12 months
A B C . E .	Clutch release arm travel	I	Every 10,000 km (6,000 miles) or 6 months
. . B C E .	Power steering system	I	Every 10,000 km (6,000 miles) or 6 months