UPPER ARM INNER BUSHING
Check for deterioration
or damage.
Replacement, page 12-22

STABILIZER BAR
Check for bending
or damage.

STABILIZER END RUBBER
BUSHING
Check for deterioration
or damage.

UPPER ARM
Check for bending
or damage.

GREASE SILICONE GREASE

COMPENSATOR ARM
Check for bending
or damage.

TRAILING ARM
Check for damage.

COMPENSATOR ARM
INNER BUSHING
Check for deterioration
or damage.
Replacement, page 12-22

REAR WHEEL
HUB UNIT
Check for cracking
or damage.

HUB UNIT BEARING
Check for play or damage.

TRAILING ARM
BUSHING
Check for deterioration
or damage.

GREASE SILICONE GREASE

LOWER ARM
Check for bending
or damage.

SPINDLE NUT
22 x 1.5 mm
Replace.
NOTE: After tightening, use a drift
punch to stake the spindle nut shoulder
onto the spindle.

STABILIZER LINKAGE
BUSHING
Check for deterioration
or damage.

GREASE SILICONE GREASE

LOWER ARM BUSHING
Check for deterioration
or damage.

GREASE SILICONE GREASE

12-21