Turn Signal/Hazard Flasher System

TURN SIGNAL INDICATOR LIGHTS
(in the gauge assembly)

LIGHTING/TURN SIGNAL SWITCH

HAZARD SWITCH
Test,page 16-30

**HAZARD SWITCH
HAZARD WARNING LIGHT**
(in the gauge assembly)

TURN SIGNAL/HAZARD RELAY
Input test, page 16-29

DASH FUSE BOX
(Located under dash, left side)