

# Troubleshooting

## Noise and Vibration

NOTE: Pump noise in first 2—3 minutes after starting in cold weather ( $-20^{\circ}\text{C}$ ,  $-4^{\circ}\text{F}$  or colder) is normal.

