Carpet/Door Sill Moldings

- Replacement

- 1. Remove:
 - Front seats (page 14-46).
 - Security compartment (page 14-52).
 - Center console (page 14-53).
 - Hood release handle.
 - Fuel filler door and tailgate openers.
 - Front of quarter trim panel.
- 2. Pry out the clips and pull up the door sill moldings.
- 3. Remove the push nuts, then separate the door sill moldings and carpet.
- 4. Pry out the clips at the rear edge and under the dashboard, peel off the tape and remove the clip nuts.

