

Timing Belt

Illustrated Index

NOTE:

- Refer to page 5-26 for positioning crank and pulley before installing belt.
- Refer to page 5-6 for alternator belt adjustment.
- Refer to page 5-7 for P/S pump belt adjustment (KQ only).
- Refer to page 5-7 for A/C compressor belt adjustment.
- Mark direction of rotation before removing.

