



8. Manual Transmission

Number	Tool Number	Description	Q'ty	Remarks
①	07GAJ-PG20101	Mainshaft Clearance Inspection Tool	1	
②	07744-0010400	Pin Driver, 5 mm	1	07944-6110100 may also be used.
③	07746-0010300	Attachment, 42 x 47 mm	1	07944-6110100 may also be used.
④	07746-0010401	Attachment, 52 x 55 mm	1	07947-6340200 may also be used.
⑤	07746-0030100	Driver	1	
⑥	07746-0030400	Driver, 35 mm	1	
⑦	07749-0010000	Driver	1	07949-6110000 may also be used.
⑧	07936-6340000	Bearing Remover Set	1	
⑨	07944-SA00000	Pin Driver, 4 mm	1	
⑩	07947-6110500	Oil Seal Driver	1	
⑪	07947-6340500	Oil Seal Driver Attachment E	1	
⑫	07948-SC20200	Oil Seal Driver	1	
⑬	07979-PJ40000	Magnet Stand Base	1	

10. Driveshafts

Number	Tool Number	Description	Q'ty	Remarks
①	07JAD-SH30100	Oil Seal Driver Attachment	1	
②	07JAF-SH20400	Support Base Attachment	1	
③	07746-0010300	Attachment, 42 x 47 mm	1	
④	07746-0010400	Driver, 52 x 55 mm	1	
⑤	07746-0010500	Driver, 62 x 68 mm	1	
⑥	07746-0030100	Inner Handle C	1	
⑦	07746-0040800	35 mm Pilot	1	
⑧	07746-0040900	40 mm Pilot	1	
⑨	07749-0010000	Driver	1	
⑩	07947-SD90100	Oil Seal Driver Attachment	1	
⑪	07947-6340201	Driver Attachment B	1	
⑫	07965-SD90100	Support Base	1	
⑬	07965-SD90200	Support Collar	1	

(cont'd)