Master Cylinder

Overhaul/Inspection

CAUTION:

- Avoid spilling brake fluid on painted surfaces as severe damage can result. Wipe up spilled fluid at onece and rinse well with clean water.
- This symbol represents brake fluid. Use only DOT 3 or 4 brake fluid.
- GREASE Use only HONDA Brake Cylinder Grease
 (P/N 08733-B020E)or equivalent.
- Carefully inspect the bore of the master cylinder for pits, scratches or scoring.
- Replace the master cylinder if the bore in damaged or worn. Do not hone or attempt to refinish the bore.
 NOTE:
- Wash all removed parts in brake fluid and blow dry with compressed air. Blow open all passages and fluid ports.
- Replace all rubber parts with new ones whenever the cylinder is disassembled.
- To prevent damage, liberally apply clean brake fluid to the piston cups before installation.
- Do not attempt to refinish master cylinder bore. Replace if pitted or worn,

