


Sunroof

Height Adjustment

The roof panel should be flush with the sunroof seal.


1. To adjust the front of the sunroof, remove the slide bracket mount bolt and add or remove shims between the slide bracket and the slide pin as shown.

NOTE: The shims should be of equal thickness on both sides.



2. To adjust the rear height, remove the lift-up link (page 14-41) and add or remove shims between the lift-up link and frame as shown.


NOTE: The shims should be of equal thickness on both sides.




Side Clearance Adjustment

If sunroof seal fits too tightly against the roof panel on one side when closed, remove the headliner, then:

1. Loosen all frame mount bolts.



2. Side-to-side fit of sunroof seal can be adjusted by moving it right or left by hand.
3. If necessary, use shims as required to make the sunroof panel fit flush with the roof panel.



3. Tighten bolts, recheck.