


Power Door Mirror


Removal

1. Remove the door panel and disconnect the power mirror connector.
2. Pry out the cover panel with a flat-tip screwdriver, then remove the cover panel.
3. Remove the mirror mounting screws while holding the mirror.



Mirror Glass Replacement

1. Heat the edge of the glass with a low powered heat gun for several minutes, then remove the glass.



2. Install the glass in the mirror case, narrow end first.

