

# Fuel Supply System

## System Troubleshooting Guide

NOTE: Across each row in the chart, the systems that could be sources of a symptom are ranked in the order they should be inspected starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next most likely system ②, etc.

PAGE		SUB SYSTEM	FUEL INJECTOR	INJECTOR RESISTOR	PRESSURE REGULATOR PRESSURE REGULATOR (CUT-OFF SOLENOID VALVE)	FUEL FILTER	FUEL PUMP	MAIN RELAY	CONTAMINATED FUEL
			62	67	68	71	72	-	*
ENGINE WON'T START				③		③	①	②	
DIFFICULT TO START ENGINE WHEN COLD OR HOT			③		③ (WHEN HOT)	②	①		
ROUGH IDLE			①		②				③
FREQUENT STALLING	WHILE WARMING UP		①			②			
	AFTER WARMING UP		①			③	②		
POOR PERFORMANCE	MISFIRE OR ROUGH RUNNING		①		②				③
	FAILS EMISSION TEST		①		②				
	LOSS OF POWER					①	③		②

\* Fuel with dirt, water or a high percentage of alcohol is considered contaminated.